

OPERATOR INSTRUCTIONS

SACP41A-HS

- STEP 1:** Confirm that circuit breaker (6CB) is switched ON and CONTROL POWER pushbutton light (1PL) is lit.
- If not, check phase monitor relay (PMR) and emergency stop (ES) button.
 - If INCORRECT POWER pushbutton light (2PL) is lit, check PMR for phase rotation and voltage setting.

STEP 2: Turn ON AIR FLOW switch (1SW).

- STEP 3:** Turn BLOWER switch (2SW) to require blower operating mode.
- VFD RUNNING pushbutton light (3PL) lit if blower is started using VFD.
 - BYPASS RUNNING pushbutton light (5PL) lit if blower is started using bypass starter.
 - Check blower circuit breaker overload (4OL) or VFD status if BLOWER TRIP pushbutton light (4PL) is lit.

STEP 4: Set blower running speed using SPD ADJ POT (potentiometer)

- STEP 5:** Cooling probe selection switch (4SW)
- Turn 4SW to ENT - Cooling is based on entering air control.
 - Turn 4SW to LVG - Cooling is based on leaving air control.

STEP 6: Turn ON COOLING switch (5SW)

- STEP 7:** Turn OFF/LOCAL/HAND/REMOTE switch (3SW) to require compressor operating mode.
- OFF - Compressor is switched off.
 - LOCAL - Compressor is operating with local controller.
 - HAND - Compressor is operating in manual mode without the controller (manual on).
 - REMOTE - Compressor is operating in remote mode without the controller (on/off by remote thermostat)

It is the customer's responsibility to always follow the written operating instructions of the unit and maintain safe work practices.