

# End User Operation Procedure

**STEP 1:** Confirm that circuit breaker (9CB) is switched ON and CONTROL POWER pilot light (2PL) is lit.

- If INCORRECT POWER pilot light (1PL) is lit, check PMR for phase rotation and voltage setting.

**STEP 2:** Turn ON FLOW switch (1SW).

**STEP 3:** Cooling probe selection switch (6SW)

- Turn 6SW to LVG - Cooling is based on leaving water control.
- Turn 6SW to ENT - Cooling is based on entering water control.

**STEP 4:** Turn ON COOLING switch (5SW)

**STEP 5:** Turn BYP/VFD switch (2SW, 3SW & 4SW) to require condenser fan operating mode.

- BYP-Condenser fan is started using bypass starter.
- VFD - Condenser fan is started using VFD.